

EMS

ELECTRONIC MICRO SYSTEMS INC.

ADDENDUM TO ALL INSTALLATION INSTRUCTIONS

INSTRUCTIONS FOR INSTALLING MULTIPLE EMS TELEPHONES ON THE SAME TELEPHONE LINE

Up to eight (8) EMS telephones can be installed on the same telephone line following the guidelines below.

When multiple EMS telephones are to share the same telephone line, programming of the set-up code and the use of power packs will be necessary. Power packs are needed when three or more EMS phones share the same telephone line. Power packs can be ordered as an option and are easy to install.

The EMS telephone has a set-up code that is programmed when multiple EMS telephones (up to 8) are installed on the same telephone line.

This feature is used to communicate with a specific telephone when multiple EMS telephones are connected to the same telephone line. This feature allows the operator to enter an identification number of the specific telephone the operator needs to communicate with. All other EMS telephones will shut off (hang up).

TO PROGRAM:

1. Using the programming instructions, enter the programming mode on an individual telephone (# 94851).
2. When in programming mode, enter the following setup code: # * 1180**18**1 * #, there will be three short tones.
3. Enter # #, you will hear a single tone.
4. Hang up.

IMPORTANT: The digit **8** (default), shown as bold type in the setup code, is the 6th digit in the sequence and represents the number the telephone will be in reference to other EMS telephones connected to the same telephone line. Each EMS telephone should be programmed with a different number (1 to 8) in relation to each other.

Example:

Elevator 1: # * 1180**11** * #

Elevator 2: # * 1180**21** * #

OPERATION:

When a call is made and multiple EMS telephones are connected to the same telephone line, all EMS telephones on this line will answer. Press * followed by the number (1 to 8) of the phone you wish to communicate with, all other EMS telephones will then turn off (hang up).